

Python API for Windows

Product Support



The following table lists the hardware supported by the MCC Universal Library Python API for Windows. OEM variants and compatible expansion devices are also supported

USB

- DEMO-BOARD
- miniLAB 1008
- SC-1608-USB
- SC-1608X-2AO-USB
- SC-1608X-USB
- Switch and Sense 8/8
- USB-1024HLS
- USB-1024LS
- USB-1208FS
- USB-1208FS-Plus
- USB-1208HS
- USB-1208HS-2AO
- USB-1208HS-4AO
- USB-1208LS
- USB-1408FS
- USB-1408FS-Plus
- USB-1602HS
- USB-1602HS-2AO
- USB-1604HS
- USB-1604HS-2AO
- USB-1608FS
- USB-1608FS-Plus
- USB-1608G
- USB-1608G
- USB-1608GX
- USB-1608GX
- USB-1608GX-2AO
- USB-1608GX-2AO
- USB-1608HS
- USB-1608HS-2AO
- USB-1616FS
- USB-1616HS
- USB-1616HS-2
- USB-1616HS-4
- USB-1616HS-BNC
- USB-1808
- USB-1808X
- USB-2001-TC
- USB-201
- USB-202
- USB-2020
- USB-204
- USB-205
- USB-231
- USB-234
- USB-2404-10
- USB-2404-60
- USB-2404-UI
- USB-2408
- USB-2408-2AO
- USB-2416
- USB-2416-4AO
- USB-2523
- USB-2527
- USB-2533
- USB-2537
- USB-2623
- USB-2627
- USB-2633
- USB-2637
- USB-3101
- USB-3101FS
- USB-3102
- USB-3103
- USB-3104
- USB-3105
- USB-3106
- USB-3110
- USB-3112
- USB-3114
- USB-5201
- USB-5201
- USB-5203
- USB-5203
- USB-7202
- USB-7204
- USB-CTR04
- USB-CTR08
- USB-DIO24/37
- USB-DIO24H/37
- USB-DIO32HS
- USB-DIO96H
- USB-DIO96H/50
- USB-ERB08
- USB-ERB24
- USB-PDISO8
- USB-PDISO8/40
- USB-QUAD08
- USB-SSR08
- USB-SSR24
- USB-TC
- USB-TC-AI
- USB-TEMP
- USB-TEMP-AI
- WEB-TC
- WEB-TEMP

Ethernet

- E-1608
- E-DIO24
- E-TC

Wireless

- BTH-1208LS